


WALLET CARD

			Button	Press Once	Press & Hold
2015 Toyota Tacoma Without JBL Sony XAV-AX6000					
Button	Press Once	Press & Hold	Back	None	None
Volume Up	Volume +	None	Enter	None	None
Volume Down	Volume -	Attenuation On/Off	Voice	Voice or Siri	None
Up	Seek +	None	Off Hook	Answer Call	None
Down	Seek -	None	On Hook	Hang Up & Reject Call	None
Mode/Hold	Source	None			
Left	Seek +	Preset +			
Right	Seek -	Preset -			